

ORIGINAL INSTRUCTIONS

OPERATING & MAINTENANCE MANUAL

SPITWATER

PRESSURE CLEANERS

SW2030

Electric Hot Water High Pressure Cleaner

Made in Australia by:

Spitwater Australia Pty Ltd T/A Ottico Equipment
953 Metry Street, Albury NSW 2640 Australia

spitwater.com



CREATORS OF

SPITWATER



WARNING: Read and understand this instruction manual before operating this unit and retain for future reference. Failure to follow operating, safety and maintenance instructions outlined in this manual releases the manufacturer from any responsibility for any accidents or damage incurred and may render any warranty void.

INTRODUCTION

Spitwater Australia is proudly Australian owned and operated since 1982. Our promise is to provide our customers with superior quality high pressure cleaners built to the highest of standards that will see many years of reliable service.

The Spitwater range of high pressure cleaners has been designed to give safe, efficient and dependable service when the correct operating and safety instructions are followed and proper attention is given to all required maintenance procedures in order to maintain the unit in peak operating condition.

This manual provides the up to date information necessary for the user to operate the unit and carry out regular inspection and maintenance.

Please note that the information given within this manual may be subject to revision in compliance with Spitwater Australia's policy of continual improvement.

Spitwater high pressure cleaners should only be used in the manner and purpose for which they were intended and in accordance with the recommendations and safety precautions detailed in this manual.

All Spitwater high pressure cleaners undergo rigorous safety and operational tests before being dispatched into the market, however it is still imperative that prior to use, all operators have read and understood all information and instructions provided and are aware of possible hazards.

GENERAL DESCRIPTION & INTENDED USE

Spitwater high pressure cleaners are specifically designed to solve all problems relating to washing, degreasing, descaling and disinfecting in a wide range of commercial and industrial situations. Some examples of applications are in the cleaning, building, transport, light and heavy manufacturing and primary industries.

SPARE PARTS, ACCESSORIES AND AFTER SALES SERVICE

Spitwater has an extensive range of spare parts and accessories to suit all your cleaning needs. For spare parts, accessories and service please contact **1800 SPITWATER (1800 774 892)** and to view Spitwater's extensive range of high pressure cleaners online visit **www.spitwater.com.au**
















For international spare parts, accessories and service please contact **enquiries@spitwater.com**

| TECHNICAL DATA | | | | |
|---|---------------------------------------|----------|----------|------------------|
| | MODEL | SW2030 | SW2030 | |
| | PRODUCT | SHW85 | SHW85/A | UNIT |
| PERFORMANCE | | | | |
| | FLOW RATE | 30 | 30 | L/M |
| | PRESSURE | 20 | 20 | MPa |
| | PRESSURE | 200 | 200 | BAR |
| | NOZZLE | 090 | 090 | |
| | OUTLET WATER TEMP MAX | 90 | 90 | °C |
| WATER INLET | | | | |
| | PRESSURE MAX | 0.6 | 0.6 | MPa |
| | TEMP MAX | 40 | 40 | °C |
| ELECTRICAL | | | | |
| | VOLTAGE | 400 | 400 | V |
| | PHASE | 3 | 3 | |
| | FREQUENCY | 50 | 50 | Hz |
| | PLUG | 32 | - | A |
| | CONNECTED LOAD | 11.8 | 11.8 | kW |
| | RATED CURRENT | 20.8 | 20.8 | A |
| | CLASS | I | I | |
| | IP PROTECTION | IPX4 | IPX4 | |
| ENGINE / MOTOR | | | | |
| | TYPE | ELECTRIC | ELECTRIC | |
| | POWER | 15 | 15 | HP |
| PUMP | | | | |
| | MODEL | T2535 | T2535 | |
| | OIL TYPE | 15W-40 | 15W-40 | |
| | OIL CAPACITY | 1.2 | 1.2 | L |
| OTHER | | | | |
| | BURNER PRESSURE | 10 | 10 | BAR |
| VALUES DETERMINED AS PER AS/NZS 60335.2.79 | | | | |
| | SOUND PRESSURE LEVEL Lp | 87 | 87 | dB (A) |
| | UNCERTAINTY Kp | 3.9 | 3.9 | dB (A) |
| | SOUND POWER LEVEL Lw + UNCERTAINTY Kw | 95 | 95 | dB (A) |
| | REACTION FORCE ON SPRAY GUN | 96.6 | 96.6 | N |
| | REACTION TORQUE ON SPRAY GUN | 29.8 | 29.8 | Nm |
| | VIBRATION ON SPRAY GUN | ≤ 2.5 | ≤ 2.5 | m/s ² |
| | UNCERTAINTY Kp | 1.5 | 1.5 | m/s ² |
| DIMENSIONS & WEIGHT (UNPACK) | | | | |
| | LENGTH | 980 | 980 | mm |
| | WIDTH | 1080 | 1080 | mm |
| | HEIGHT | 1216 | 1216 | mm |
| | WEIGHT | 498 | 498 | Kg |

The manufacturer reserves the right to modify designs, features and technical data without notice.

DESCRIPTION OF SYMBOLS

The following symbols are used throughout this instruction booklet in order to mark important paragraphs or sections that require particular attention. Their meaning is listed next to them for your attention.

| | | | | | |
|---|---|---|---|---|--|
|  | WARNING: Failure to follow instruction could result in serious injury or even death |  | WARNING: Failure to follow instruction could result in damage to unit |  | TIPS AND INSTRUCTIONS to ensure safe and proper operation |
|  | PERSONAL PROTECTIVE EQUIPMENT (PPE) Eye protection recommended |  | PERSONAL PROTECTIVE EQUIPMENT (PPE) Ear protection recommended |  | PERSONAL PROTECTIVE EQUIPMENT (PPE) Safety boots recommended |
|  | PERSONAL PROTECTIVE EQUIPMENT (PPE) Respiratory protection |  | PRESSURE GAUGE |  | CHEMICAL INJECTOR OPEN / CLOSE |
|  | OIL INDICATION |  | UNIT ON / OFF |  | VISUAL CHECK / VERIFICATION |
|  | MANUAL ASSEMBLY |  | USE APPROPRIATE SPANNER |  | AUTHORIZED SPITWATER SERVICE AGENT |

The following symbols are used on the unit in order to warn user of potential injury if not cautious. Their meaning is listed next to them for your attention.

| | | | |
|---|--|---|---|
|  | CAUTION Hot surface. Do not touch |  | CAUTION Electric shock hazard. Disconnect power before removing cover. |
|---|--|---|---|




IMPORTANT SAFETY INSTRUCTIONS AND PRECAUTIONS

WARNING: This high pressure cleaner shall only be used by persons instructed in its use and who have been authorized to do so. Before using this high pressure cleaner please pay particular attention to the following safety warnings as failure to do so could result in serious injury or even death.

SAFETY LABELS, UNIT COMPONENTS FEATURES & CONTROLS



- Always pay attention to the safety instructions provided on each label. Do not alter or remove safety labels



GENERAL SAFETY PRECAUTIONS




1. OBSERVE SAFETY INSTRUCTIONS

- Make sure you have read and understood the whole instruction manual before installing, operating or carrying out any maintenance on this unit.
- Warnings and serial label on the unit provide important directions and information on the safe use of the unit.
- In addition to these operating and safety instructions please make sure that all accident prevention regulations applicable in the country of use are followed.
- In addition to these operating and safety instructions any standards relating to the installation and operation of high pressure cleaners applicable in your country must be strictly followed.
- This unit is not intended for use by children. Children must always be supervised when in the vicinity and ensure that they **DO NOT** play with the unit. Further, it is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience or knowledge. It must only be operated by persons instructed in its use who have been especially authorized to do so.
- **DO NOT** operate the unit without appropriate personal protective equipment PPE.




2. ELECTRICAL CONNECTION

- The voltage, hertz rating and number of phases on the serial label must correspond to that of the electrical mains outlet.
- Only connect the unit to electrical installation made by **certified electrician and comply with IEC 60364-1**.
- It is recommended that the electrical supply to this unit should include either a residual current device that will interrupt the supply if the leakage current to earth **exceeds 30mA for 30 ms** or a device that will prove the earth circuit.
- Switching on the unit may cause voltage fluctuations. Voltage fluctuations should not occur if the impedance of the transfer point is less than 0.15Ω . If in doubt contact your power supplier.
- This Class 1 Appliance must only be connected to an earthed power supply fitted with an appropriately sized fuse.



3. POWER CORD


- Make sure before every use that the power cord assembly is not damaged or cut. If it is **DO NOT** connect the unit, have it replaced by an electrician or authorized service technician. (**Type Y attachment**)
- **DO NOT** pull on the power cord in order to unplug the unit, remove the plug from the power outlet.





4. EXTENSION CORD

- If using an extension cord make sure it is according to cross section / maximum length requirements as shown to the right.
- Inadequate extension cords can be dangerous. If an extension cord is used, it shall be suitable for outdoor use, and the connection has to be kept dry and off ground. It is recommended that this is accomplished by means of a cord reel which keeps the socket at least 60mm above the ground.
- Make sure the extension cord is fully unrolled, kept dry, away from traffic, sharp edges and heat to avoid damage or cuts.
- If using an extension cord make sure it is not connected to mains voltage when connecting / disconnecting to the unit's power cord.



| LENGTH | |
|--------|--------------------|
| 0-10m | |
| <15A | 2.5mm ² |
| <25A | 4.0mm ² |



5. TRIP HAZARD

- Loose extension cords and power cables provide a potential trip hazard, especially when they cross pathways.
- Take safety measures like placing traffic cones along the cord or tape the cord to the floor with duct tape.



6. FIRE PREVENTION AND HOT SURFACE CAUTION

- Store flammable fluids in approved containers and cabinets away from sparks and heat.
- To avoid fire, be alert for leaks of flammable substances from hoses and lines.
- The exhaust gases and chimney are very hot. To prevent a fire, do not expose dry grass, mowed grass, oil or any other combustible material to exhaust gas. Be cautious, to avoid burns.
- Be sure to stop the unit before cleaning the unit.
- Under NO circumstance use flammable liquids, undiluted acids or solvents as a chemical as the spray produced would be highly flammable.



7. EXHAUST & FLUE GASES

- Unit exhaust fumes can be very harmful if allowed to accumulate. Be sure to run the unit in a well vented location and where there are no people or live stock near the unit.
- Ensure that any exhaust emissions are not in the vicinity of air intakes.





8. SAFE HANDLING OF FUEL AND LUBRICANTS

- Always turn off the unit and let the unit cool down before refueling and/or lubricating.
- DO NOT smoke or allow flames or sparks in your work area. Fuel is extremely flammable and explosive under certain conditions.
- Refuel in a well ventilated and open area. When fuel and/or lubricants are spilled clean immediately.
- DO NOT mix petrol or alcohol with diesel fuel. Incorrect fuels shall not be used as they may prove hazardous.
- Use only clean and approved fuel, store in appropriate containers and dispensers.



9. CHECKS AND SERVICE

- Inspect the unit each day before use. Follow “Daily inspection check list” guide *Table-B* in the SERVICE / CARE section.
- Service the unit regularly based on its usage. Follow “Usage vs Service frequency” matrix (*Table-A*) in the SERVICE / CARE section.




OPERATIONAL SAFETY PRECAUTIONS

All health and safety regulations applicable to general safe work practices, as well as safe operation of equipment, as well as any specific standard for safe operation of high pressure cleaners according to local regulations must be followed. When operating this unit,




1. PERSONAL SAFETY

- Personal protective equipment (PPE) must be worn when operating this unit including footwear, clothing, eyewear and all other necessary equipment according to regulations and requirements.
- Always wear appropriate ear protection if the noise level indicated in the technical data of this appliance exceeds 80dB (A).
- When operating the unit be alert and hold onto the gun and lance firmly with both hands.
- When the gun is operated, the user is subject to very strong recoil forces and torque.



- There is a risk of high pressure water jet injury. Never aim the jet at yourself, other people or animals as this could result in serious injuries or even death.
- There is a risk of electrocution. Never aim the water jet at the unit itself or other live electrical equipment as this could result in serious injury or even death.
- Depending on the application of high pressure cleaners, hydrous aerosols may be formed. The employer shall perform a risk assessment in order to specify the necessary protective measures regarding aerosols, depending on the surface to be cleaned and its environment. Shielded nozzles can be used for high pressure cleaning, which will reduce the emission of hydrous aerosols dramatically **OR respiratory masks of class FFP 2, an equivalent or higher are suitable for the protection against hydrous aerosols.**





2. WORK ZONE SAFETY

- The work zone must be kept clear of all persons not authorized to be there. If other people must be in the work area they too must wear all necessary personal protective equipment and must be aware of the existing hazards / risks.
- This unit must not be operated in hazardous areas. Also to prevent fire hazards it must not be operated near inflammables such as petrol, grain dust, solvents, thinners etc.
- When operating the unit make sure the operating area is not releasing health or environmental hazardous substances (e.g. asbestos, oil etc)



3. EQUIPMENT SAFETY

- Never exceed the maximum working temperature and pressure as indicated on the unit data plate and in this manual.
- Only use this unit with cleaning chemicals recommended by Spitwater. The use of other cleaning agents or chemicals may adversely affect the safety of the unit.
- Never operate the unit without water as even a brief operation without it will cause severe damage to the pump and other components.
- When finishing work, switch OFF the unit and release any trapped pressure in the hose and engage the gun trigger lock.
- Never leave the unit unattended while it is running.
- Never lock the spray gun trigger in the open position.
- Never use accessories or spare parts that were not designed for use with this unit as this could cause damage to the unit. Spitwater recommends the use of original accessories and spare parts available through Spitwater and its extensive dealer network.
- Never use a nozzle size other than that specified in the technical data. Using the wrong size nozzle could damage the unit.
- Keep flammable materials away from, and do not place anything on the unit while it is running.

SAFETY FEATURES OF THE UNIT

Pressure regulating valve: This unit is equipped with a pressure regulating valve which prevents damage to the unit by keeping the system pressure safely below a desired limit. When the system pressure exceed the setting of the valve spring, the fluid unseats the valves and bypasses to the reservoir.

Pressure switch: This unit is also equipped with a pressure switch which prevents the operation of the burner, if adequate water pressure is not detected at pump. Keeping the burner off, when there is no water flow will eliminate the potential risk of steam generation and explosion. Also it turns on the timer function of the unit.

Flow switch: This unit is equipped with a flow switch to determine the presence of water flow and sends signal to start the pump, when there is water flow it will shut off the unit. This will eliminate the risk of operating the pressure cleaner without water.

Timing device: This unit is equipped with a pre-set timing device. The timer will shut down the unit if it is left in bypass for longer than 5 minutes.

Safety valve: This acts as a fail-safe system. When the system pressure exceeds the set value, the valve opens proportionally with increase in pressure and release the excess pressure out and resets back.




Low level water cut-off: This unit is equipped with a low level cut off sensor. The unit will be shut off in case of low water level to avoid damage to the pump.


Emergency stop: This is a manually operated push button, which shuts OFF the whole unit.





In case of EQUIPMENT FAILURE / BREAKDOWN turn the unit OFF and see "SERVICE / CARE RECOMMENDATIONS AND DIY TROUBLESHOOTING GUIDE" section.

STORAGE / TRANSPORT

-  1. For safe movement of the unit between work areas make sure that the unit has been switched off. Allow it to cool down if necessary. Bleed of any trapped pressure according to instructions and confirm all safety locks are engaged.
-  2. The safest way to lift the unit is to use the forklift. DO NOT lift the unit from the side. (Refer below figure)
-  3. For safe transportation in and on vehicles make sure the unit is appropriately strapped, in order to prevent it from sliding or falling.



-  4. If transporting the unit make sure there is no possibility for the temperature to be at or below 0°C. If it is necessary to transport the unit at or below 0°C contact your authorized Spitwater service agent for advice.
-  5. When not in use the unit must be stored in a dry building where there is no possibility for the temperature to be at or below 0°C. If necessary to store the unit at or below 0°C contact your authorized Spitwater service agent for advice.
6. Keep detergent lines clean and flush regularly especially if the unit is not used often.



PROTECT FROM FROST

ASSEMBLY & INSTALLATION GUIDE


1. Caution should be taken when lifting the unit. Always adopt safe lifting techniques in order to avoid damage to the unit and injuries to person.
2. Remove carton and carefully remove the unit from the pallet keeping it upright. Visually check for any damage, leaks or other issues. If any problem is found, contact your Spitwater agent immediately.
3. Identify the unit from the information on the serial label affixed to the unit.

| | | | | | |
|---|------|----------------------|--|----------------------------|--|
| SCW85 | | HP2030 | | SPITWATER AUSTRALIA | |
| Made in Australia | | | | | |
| Year | | IP Rating | | IPX5 | |
| Rated voltage (V) | | Rated flow (L/M) | | 15 | |
| Rated current (A) | 12.5 | Rated pressure (MPA) | | 20 | |
| Rated freq. (HZ) | 50 | Weight (K) | | 145 | |
| S/N | | | | | |
|  | | | | | |
| 953 METRY STREET, NORTH ALBURY, NSW, 2641 | | | | | |

4. The unit must be positioned on flat stable ground and must be in an upright position before operating. Do not operate on an uneven surface or on loose gravel.
5. Connect the high pressure cleaner to the power supply making sure that the voltage supply is as specified on the data plate and in the technical data in this manual. This unit must be earthed. Please note that incorrect voltage or insufficient power supply will cause immediate damage to the unit.

Note: Any work needed on initial installation to connect the unit to the power supply must be carried out by a qualified electrician in accordance with local standards and regulation.
6. PLUG ASSEMBLY **(SHW85/A ONLY)**
 - Only a certified Electrician should carry out this task.
 - Plug should comply with Technical data table of this unit.
 - Class 1 Appliance must only be connected to an earthed power supply fitted with an appropriately sized fuse.


7. Replace the red oil travel plug fitted on the pump with the yellow dipstick supplied in the accessories bag.



8. Check the oil level in the pump using the dipstick or the sight glass on the back / side of the pump. Make sure the level is between min/max level notches on the dipstick, or is level with the indicator on the sight glass. If oil reservoir needs replenishing only use oil of a type as listed in the data sheet in this instruction manual.


9. NOZZLE ASSEMBLY

Connect the high pressure nozzle (smaller hole) and the low pressure nozzle (larger hole) to the lance. Do not over tighten and make sure that the nozzle positions do not interchange during assembly. Add nozzle shield after nozzle assembly. Refer diagram below.




10. LANCE, TRIGGER GUN & HIGH PRESSURE HOSE ASSEMBLY

- Connect the lance to the spray gun by an in-built quick release coupling.
- Connect the high pressure hose fitting to the spray gun. Do not over tighten.
- Connect the quick release adaptor to the high pressure hose fitting. Do not over tighten.



11. ASSEMBLY OF HIGH PRESSURE HOSE WITH THE UNIT


- Connect the quick release high pressure hose to the outlet connector of the unit.



- *High pressure hoses, fittings and couplings are important for the safety of the machine. Use only high pressure hoses, couplings and fittings recommended by Spitwater.*
- *Do not pull on high pressure hose in order to move the unit.*

12. WATER INLET CONNECTION

- Connection to potable water mains can be achieved by using a general garden hose set (3/4 inch diameter) and a hose clamp.
- Connect the water supply hose to the water inlet connection. In case of poor water quality the use of an external water filter is recommended. Contact your Spitwater agent for advice and /or supply.
- Make sure the water supply temperature and pressure meet the values specified in the technical data, then turn the water supply on. Visually check for leaks and contact your Spitwater service agent if found.
- Open the water supply and fill the water tank. The float valve will automatically stop the water flow when the water tank is full.
- Water that has flowed through backflow preventer is considered to be non-potable (non-drinkable).
- For suction supply / non-pressure water supply, other than potable water mains, contact your authorized Spitwater service agent for advice.




WARNING:

- *This high pressure cleaner is only allowed to be connected with the drinking water mains, when an appropriate backflow preventer has been installed, AS/NZS 60335.2.79.*
- *Follow all local standards and regulations applicable to water connection.*



13. Remove the DIESEL tank cap and fill the diesel tank with clean filtered diesel. **ONLY USE CLEAN DIESEL IN THIS UNIT**, as using any other fuel will create a risk of explosion and damage to the unit.





OPERATING INSTRUCTIONS

GENERAL PRE-START CHECK


1. Inspect the unit every day to confirm that it is safe and in proper working order before putting it into service. Follow the “**DAILY INSPECTION CHECK LIST**” in the SERVICE / CARE section as a guide. If the unit is damaged or faulty in anyways, **DO NOT** use it and immediately contact your authorized Spitwater service agent for advice.

TO START


1. Always wear appropriate Personal Protective Equipment. (PPE)



2. Press the ON power button (I).




5 Seconds Rule: *DO NOT* pull the trigger for the first five seconds once pressing the ON power button (I).





TO USE

1. Release the spray gun trigger lock.
2. Pull the trigger on the spray gun and allow water to run through the system for a few minutes to expel air from the hydraulic system. If air remains in the system, open and close the spray gun a few times to expel. **Note:** *If this is the first use of the unit or the unit has been left idle for an extended period of time it is advisable to run this operation with the front part of the lance disconnected in order to avoid debris or scale being lodged in the nozzle and blocking it.*



3. Check that the pressure indicated on the pressure gauge matches the value on the data plate and in the technical data. Also check that when the trigger is released the pressure shown on the gauge returns to zero.





HOT WATER MODE

- USAGE TIPS:**
- Use the unit as necessary to carry out cleaning while trying to minimize where possible opening and closing the spray gun trigger as this will lead to premature wear of the parts.
 - Do not hold the nozzle too close to the surface to be cleaned as this may damage the nozzle. Start cleaning at a comfortable distance and work closer as necessary.


1. If hot water is required, turn the burner switch clockwise to ON position.

PRESSURE ADJUSTMENT HIGH / LOW


1. To activate high pressure turn the lance handle clockwise and pull the trigger and to activate low pressure turn the lance handle anti-clockwise.



2. Turn the temperature adjustment knob to achieve desired cleaning temperature.




3. After hot water use, turn burner switch in anti-clockwise to turn OFF the hot water and change back to cold water mode for cleaning.




TO STOP

1. Make sure burner switch is in OFF position.
2. Press the OFF power button (0) of the unit.










3. Release all trapped water pressure in the unit by pulling the trigger of the spray gun, then engage the spray gun trigger lock. Failure to follow this instruction will leave the unit in a potentially unsafe manner.





SERVICE / CARE RECOMMENDATIONS AND DIY TROUBLESHOOTING GUIDE

SAFETY PRECAUTIONS

-  1. To ensure machine safety, use only original spare parts from the manufacturer or approved by the manufacturer.
-  2. Carry out all regular maintenance and inspections as listed in this manual using original Spitwater parts where required.
-  3. Always make sure before carrying out any maintenance that the unit is turned off, allowed to cool down and any trapped high pressure in its system has been released.
-  4. Never carry out any maintenance work not specifically outlined in this booklet and never make any technical modifications to this unit.
-  5. This unit is fitted with safety devices which are set and sealed at the factory. It is very important these devices receive their routine maintenance to assure your safety as well as necessary protection of the unit.
-  6. There are a number of important components that have been set and sealed at the factory. Never under any circumstances tamper with, modify or adjust these settings.
-  7. Make sure this unit is regularly serviced by an authorized Spitwater service agent according to the servicing requirement outlined in this booklet.

SERVICE INSTRUCTIONS

To maintain this unit in peak working condition during its operating life it is necessary to carry out regular maintenance operations and replace worn or broken parts immediately upon their failure. Spitwater recommends that all maintenance is carried out by an authorized Spitwater service agent using original Spitwater spare parts.



Failure to follow the maintenance guidelines in this manual releases the manufacturer from any responsibility in reference to injuries and damages to both persons and goods.



Always dispose of oil, batteries, chemicals and unused equipment safely and according to the requirements of local authorities

DAILY INSPECTION CHECK LIST































| | | CHECKED & OK |
|---|---|--|
| | | ATTENTION REQUIRED |
| DAILY CHECKS BEFORE UNIT START | | |
|  |  | Ensure all guards, covers and shields are in place before operating the unit. |
|  |  | Check the power cable / electrical plug for any cuts, abrasions or damage. |
|  |  | Check for water leaks at supply inlet and other hose connections. |
|  |  | Check high pressure hose for kinks, damage or exposed braids. If the hose is damaged in any way the unit must not be used and the hose must be replaced immediately. |
|  |  | Clean off dust or other foreign matter accumulated on the chimney. Wipe up any spills immediately. |
|  |  | Check pump oil and fuel levels. Make sure no leaks appear. |
|  |  | Make sure oil colour has not gone "milky" in appearance. |
|  |  | Check for any service due, based on "USAGE VS SERVICE FREQUENCY" Table-A. |
| CHECKS DURING UNIT RUN | | |
|  |  | Proper function of burner switch, temperature controller, emergency stop and pressure gauge. |
|  |  | Check for water leaks at high pressure hose fittings. |
|  |  | Check pressure gauge to show working pressure as per Technical data sheet, when the trigger is in ON position. |
|  |  | Color of exhaust fumes. <ul style="list-style-type: none"> • Dark fumes = abnormal condition, unit needs attention. • Clear fumes = ideal condition to run the unit. |
|  |  | Assess any undue noise levels from the motor. |
|  | Unit is fit, proceed task |  STOP operating the unit, Contact Spitwater service agent immediately |
|  | Contact Spitwater service agent / Qualified person for assistance |  Do It Yourself, Refer our tips |

TABLE-B: Daily inspection checklist

USAGE VS SERVICE FREQUENCY

| | | | |
|--|--|--------------------|---------------------|
| | MORE THAN 6 TO 8 HOURS DAILY | SERVICE ONCE EVERY | 1 Month |
| | 4 TO 6 HOURS DAILY | SERVICE ONCE EVERY | 3 Months |
| | WEEKLY USE | SERVICE ONCE EVERY | 6 Months |
| | INFREQUENT or MONTHLY USE | SERVICE ONCE EVERY | 12 Months |


TABLE-A: Usage vs Service Frequency



Time interval for checks and replacement listed above are for units subjected to normal operating conditions. Should the unit be subjected to abnormal conditions (e.g. heavy use, dirty water, extreme temperatures or conditions etc.) times should be reduced accordingly.

OIL CHECK POINTS

PUMP OIL CHECK




PUMP OIL CHECK

Ensure the unit is on a flat surface.

Remove the fastening knob and the oil level cap.

Check the oil level in the pump using the dipstick or the sight glass on the back / side of the pump. Make sure the level is between min/max level notches on the dipstick, or is level with the indicator on the sight glass



TROUBLESHOOTING GUIDE



If the fault cannot be identified or corrected using the below list (or remedy suggests contacting Spitwater service agent) stop using the unit immediately and contact your authorized Spitwater service agent to rectify.

| TROUBLESHOOTING GUIDE | | |
|---|--|---|
| FAULT | CAUSE | REMEDY |
| Pump is running but does not reach rated pressure | Pump sucking air | Check hose / fittings for leaks |
| | Nozzle is blocked / worn | Remove and clean nozzle |
| | Water filter dirty | Check and clean water filter |
| Fluctuating pressure | Pump sucking air | Check hose / fittings for leaks |
| | Nozzle is blocked / worn | Remove and clean nozzle |
| | Water filter dirty | Check and clean water filter |
| Pump is noisy | Pump sucking air | Check hose / fittings for leaks |
| Appearance of "milky" oil in the pump | | Contact Spitwater service agent |
| Water leaking from pump | | Contact Spitwater service agent |
| Oil leaking from pump | | Contact Spitwater service agent |
| The motor does not start when switch is activated. | Plug is not connected. | Check the plug. |
| | If fitted: Low water cut off is activated. | Check that water / diesel tank are full and add water / diesel as necessary. |
| | No power supply. | Contact an authorized electrician to check power supply. |
| When switch is activated the motor hums but does not run. | Incorrect extension cable. | See instructions in manual and replace with an extension cord of correct size and length. |
| | Incorrect or insufficient voltage or amperage. | Contact an authorized electrician to check power supply. |
| | Failed capacitor | Contact Spitwater service agent |
| The motor stops | | Contact Spitwater service agent |

TABLE-C: Troubleshooting guide



For service of your Spitwater high pressure cleaner within Australia, call **1800SPITWATER** or visit **www.spitwater.com.au** for further contact details.